

IMPERIAL FLOORING AUSTRALIA®

ARCHITECTURAL SPECIFICATION

14mm Engineered Timber Flooring Collection

1. PRODUCT DESCRIPTION

14mm Engineered European Oak Timber Flooring comprising a 2mm solid European Oak wear layer bonded to a multi-layer structural plywood core for enhanced dimensional stability and performance.

Finished with a brushed super-matt UV lacquer (5–8% gloss level), providing durability, scratch resistance and a natural timber aesthetic.

2. PERFORMANCE CHARACTERISTICS

- Engineered multi-layer construction for dimensional stability
- UV-cured lacquer for enhanced wear resistance
- Suitable for installation over concrete slabs and timber subfloors when prepared to specification
- Compatible with hydronic in-slab heating when installed via Direct Stick method

3. INSTALLATION SPECIFICATION

Installation is recommended to be carried out by a qualified flooring installer in accordance with Australian Standards and Imperial Flooring Australia installation guidelines.

4. TECHNICAL SPECIFICATIONS

Brand	Imperial Flooring Australia®
Timber Species Grade	European Oak ABCD
Construction	Multi Layer Cross Plywood
Board Dimensions	1900mm (Length) x 190mm (Width)
Thickness Top Layer	14mm 2mm Veneer
Surface Finish	Brushed UV Lacquer Matte Finish
Joining System	Tongue + Groove
Edging	4 Sided Micro-Bevel
Installation Method	Direct Glue Down Floating Floor
Pack Size	2.166 m ² 6 x Boards 21kgs <small>< 25% Nested Random Shorter Boards</small>
Slip Test Rating	P3
Fire Report Rating	CHF Value: 4.1 kW/m ² Smoke Value: 44 %.min
Warranty	Residential: 20 Years Commercial: On Request



CREAM WHITE



NATURAL OAK



LIGHT BROWN



WHITE HAVEN



PALE OAK



TUSCAN OAK



COUNTRY OAK



CEDAR BROWN



BLACK OPAL

5. GENERAL SITE REQUIREMENTS

- Building must be weather-tight and fully enclosed
- Wet trades completed and areas fully dry
- HVAC operational where applicable
- Subfloor must be structurally sound, clean, dry and level
- Maximum subfloor flatness tolerance: **3mm deviation over 3 metres**
- Concrete slabs must be fully cured (New Builds)
- All concrete substrates must be sealed with an approved moisture barrier system
- Flooring must be acclimatised within installation area prior to laying
- Expansion gaps must be provided at all vertical obstructions

6. INSTALLATION METHOD A – DIRECT STICK (FULL GLUE-DOWN)

Recommended Application

Preferred method for maximum stability and for areas where fixed cabinetry or heavy joinery will be installed.

Subfloor Preparation

- Apply approved moisture barrier to concrete substrates
- Allow moisture barrier to cure as per manufacturer instructions
- Subfloor must meet flatness tolerances 3mm over 3mtrs

Adhesive Application

- Use approved timber flooring adhesive
- Apply using manufacturer-recommended notched trowel
- Ensure continuous adhesive coverage – no voids
- Install boards into wet adhesive and press firmly for full contact

Laying Procedure

- Maintain minimum **8mm** perimeter expansion gap
- Stagger end joints minimum 450mm
- Remove excess adhesive immediately
- Use tapping block to ensure tight joints
- Allow full adhesive cure before foot traffic (as per adhesive manufacturer)

Fixtures & Joinery

- Heavy cabinetry, kitchen islands and fixed joinery may be installed over direct stick flooring

7. INSTALLATION METHOD B – FLOATING FLOOR SYSTEM

Recommended Application

Suitable for residential installations where floor is not mechanically fixed to substrate.

Subfloor & Underlay

- Install approved acoustic or floating floor underlay
- When over concrete, underlay must incorporate vapour barrier at minimum
- Subfloor must meet flatness tolerances 3mm over 3mtrs

Board Installation

- Apply continuous PVA adhesive to tongue and groove joints (do not spot glue)
- Engage boards and tap gently into position
- Maintain minimum **10mm** perimeter expansion gap
- Stagger end joints minimum 450mm
- Do not mechanically fix boards to subfloor

Restrictions

- Heavy cabinetry, kitchen islands or fixed joinery must not be installed over floating floors

8. FULL INSTALLATION GUIDE LINK:

www.imperialflooringaustralia.com.au/engineered-timber-flooring-install-guide

9. CURING AND FINISHING STEPS

- Allow adhesive to cure for 8–12 hours minimum (or as specified by adhesive manufacturer) before light foot traffic.
- Do not place heavy furniture until full cure is achieved.
- Remove spacers once curing is complete.
- Reinstall skirting or trims by fixing to the wall only, not the floor.
- Minor gaps may be filled using colour-matched filler or cork compound (test on offcut first).

For final cleaning, use mineral spirits, turpentine or acetone to remove any adhesive residues. then a final clean with wood ph floor cleaner. Do not flood the floor with water.

10. SITE FLOOR PROTECTION (New Builds + Renovations)

On active building sites, newly installed flooring must be protected immediately to prevent damage. Use breathable floor protection systems. Protection must allow airflow and must not trap moisture.

11. UNDERFLOOR HEATING REQUIREMENTS

- Compatible with hydronic in-slab heating systems only
- Suitable for Direct Stick (Full Glue-Down) installation method only
- Floating installation is not approved over underfloor heating
- Maximum floor surface temperature must not exceed 26°C
- Heating system must be commissioned gradually
- Increase and decrease temperature in controlled increments
- Electric underfloor heating systems are not approved

12. CARE & MAINTENANCE

- Clean using recommended timber floor cleaning products
- Avoid excessive water or steam cleaning
- Fit protective pads to furniture
- Use entry mats to reduce abrasive wear
- Protect floor during construction works

13. COMPANY DETAILS**Imperial Flooring Australia[®] Pty Ltd**

📍 1 Kennedy Ave, Yallah NSW 2530 (Wollongong)

✉ info@imperialflooringaustralia.com.au

☎ 1300 676 176

Website: www.imperialflooringaustralia.com.au

Disclaimer

Installation must be carried out by a qualified flooring professional and in accordance with this guide and relevant Australian Standards. Imperial Flooring Australia[®] accepts no responsibility for failure resulting from improper installation, inadequate subfloor preparation, moisture issues, or non-compliant site conditions.